

CHINA (6135JZ caf)

ITEM	PART NO.	中文名称	ENGLISH DESCRIPTION
1	342-070	高压油管总成	HIGH PRESSURE FUEL PIPE ASSY
2	344-010	喷油器和油管总成	HIGH PRESSURE FUEL PIPE ASSY
3	386-1/10 x 22	铜垫片	COPPER WASHER
4	386-1/8 x 12	铜垫片	COPPER WASHER
5	435E (3127E-10)	油嘴	NOZZLE
6	437D (3127D-10)	油嘴偶件	NOZZLE COUPLE
7	6135JZCAF FUEL PUMP+GOVERNOR	高压油泵总成 (含调速器)	FUEL PUMP+GOVERNOR
8	741G-02-004	放水阀	DRAIN COCK
9	761-04-041a	排气阀杆	EXHAUST VALVE SPINDLE
10	761-04-042a	进气阀杆	INTAKE VALVE SPINDLE
11	761-05-005c	连杆螺钉	CONNECTING ROD BOLT
12	761-05-009A	活塞销	PISTON PIN
13	761-05-010c	连杆总成	CONNECTING ROD ASSEMBLY
14	761-26-140d	PIPE ASSY, INJECTION LEAK-OFF	PIPE ASSY, INJECTION LEAK-OFF
15	761-28-001d	喷油器	INJECTOR
16	761-28-002c	压力调节螺栓	PRESSURE ADJUSTING SCREW
17	761-28-005a	压力调节螺母	PRESSURE ADJUSTING NUT
18	761-28-006b	调压弹簧	SPRING, PRESSURE REGULATING
19	761-28-008C	喷油器接头	CONNECTION, FUEL INLET
20	761-28-009C	喷油器滤芯	FILTER CONE
21	761-28-011a	帽盖	INJECTOR CAP
22	761-28-019a	帽	CAP
23	761-28-020b	杆	ROD ASSY
24	761-28-022	铜垫片	COPPER WASHER
25	761-28-024a	弹簧座, 上部	SPRING SEAT, UPPER
26	761-281-000	喷油器总成	INJECTOR ASSEMBLY
27	761-28I-000	喷油器总成	COMPLETE INJECTOR
28	761G-02-004	排气阀旋塞	DRAIN COCK
29	761G-02-032A	缸盖垫片	CYLINDER COVER COPPER GASKET
30	761G-04-014B	进气管垫片	GASKET INTAKE MANIFOLD
31	761G-04-015a	排气管垫片	EXHAUST GAS MANIFOLD GASKET
32	761G-04-020b	缸盖	CYLINDER HEAD
33	761G-04-034a	气门锁夹	VALVE SPRING RETAINER LOCK
34	761G-05-001F	活塞	PISTON
35	761G-20-010	水密封 (型号F20)	WATER SEAL (F20 TYPE)
36	761G-20-010	水密封	WATER SEAL
37	761G-20-010 IIF20	淡水/海水泵密封	SHAFT SEAL FOR FRESH WATER PUMP
38	761G-20-036	螺母	CROWN NUT
39	761G-26-010B	高压油管	INJECTION P/P ASSEMBLY-CYL. #1
40	761G-26-014B	低压油管总成0.30M	FUEL HOSE ASSY. INJECTION PUMP INLET
41	761G-26-020B	高压油管	INJECTION P/P ASSEMBLY-CYL. #2
42	761G-26-030B	高压油管	INJECTION P/P ASSEMBLY-CYL. #3

43	761G-26-040B	高压油管	INJECTION P/P ASSEMBLY-CYL. #4
44	761G-26-050B	高压油管	INJECTION P/P ASSEMBLY-CYL. #5
45	761G-26-054A	低压油管总成0.90M	FUEL HOSE ASSY. FEED PUMP TO FILTER
46	761G-26-060B	高压油管	INJECTION P/P ASSEMBLY-CYL. #6
47	761W-02-002b	缸套	CYLINDER LINER
48	761W-04-002b	排气门座圈	EXHAUST VALVE GUIDE SEAL RING
49	761W-04-003b	进气门座圈	INTAKE VALVE GUIDE SEAL RING
50	761Z-04-003a	进气门座圈	INTAKE VALVE GUIDE SEAL RING
51	761Z-04-009	进气门	INLET VALVE
52	761Z-04-011	进气管垫片	AIR INLET MANIFOLD GASKET
53	761Z-04-020	缸盖	CYLINDER HEAD
54	761Z-05-001	活塞	PISTON
55	762D-20-000	淡水泵	COMPLETE PUMP
56	762D-21-004	轴	SHAFT
57	762D-21-010	海水泵密封	SHAFT SEAL FOR SEA WATER PUMP
58	762D-21B-000	海水泵	SEA WATER PUMP
59	762D-21b-002	密封环	SEAL RING
60	762D-21b-004	轴	SHAFT
61	762D-21b-005	叶轮	IMPELLER
62	762D-21b-008	轴套	SLEEVE, SHAFT
63	762D-21b-011	压板	DISK
64	762D-21b-012	压板	DISK
65	762D-35-000	热交换器	HEAT EXCHANGER ASSEMBLY
66	762D-35-007	热交密封条	RUBBER SEAL
67	763C-02-001	缸套	CYLINDER LINER
68	763Ca-04-005	进气阀杆	INTAKE STEM VALVE
69	772-21-017a	锁紧垫片	LOCK WASHER
70	772-21-018a	垫片	WASHER
71	8 x 14 / 386-1	垫片	GASKET
72	A-3 d x 10 GB 119-76	销	PIN
73	A761-04-020	缸盖	CYLINDER HEAD
74	A761-05-001a	活塞	PISTON
75	A761-05-004	活塞销	PISTON PIN
76	A761-05-010	油环	OIL SCRAPER RING
77	A764Z-04-001	进气管垫片	AIR INLET MANIFOLD GASKET
78	A764Z-05-001	活塞	PISTON
79	C 5 x 16GB 1096-72	平键	KEY
80	C 6 x 20GB 1096-72	平键	KEY
81	C0810A-0000	燃油滤清器结合组	FUEL OIL FILTER ELEMENT
82	C0810B-0000	燃油滤清器结合组	FUEL OIL FILTER ELEMENT
83	C5x16 GB 1096- 72	键	KEY
84	C6x20 GB 1096- 72	键	KEY
85	M14 x1.5x30 / 512-1	连接螺栓	JOINT BOLT
86	M16x1.5 GB52 - 76	轴螺母	NUT
87	M8x1x20 / 512-1	连接螺栓	JOINT BOLT