

MAN B&W (T23L)

| ITEM | PART NO. | 中文名称 | ENGLISH DESCRIPTION |
|------|---------------------|------------------------------|-----------------------------|
| 1 | 3050-17HI-5352 | 垫圈 | GASKET |
| 2 | 3050-17HI-6064 | 垫圈 | GASKET |
| 3 | 30502-11-2771 | 上轴瓦 | UPPER BEARING SHELL |
| 4 | 30502-11-2771U/S0.5 | 上轴瓦 加厚0.5MM | UPPER BEARING SHELL U/S 0.5 |
| 5 | 30502-11-2771U/S1 | 上轴瓦 加厚1MM | UPPER BEARING SHELL U/S 1 |
| 6 | 30502-11-2771U/S1.5 | 上轴瓦 加厚1.5MM | UPPER BEARING SHELL U/S 1.5 |
| 7 | 30502-11-2959 | 下轴瓦 | LOWER BEARING SHELL |
| 8 | 30502-11-2959U/S0.5 | 下轴瓦 加厚0.5MM | LOWER BEARING SHELL U/S 0.5 |
| 9 | 30502-11-2959U/S1 | 下轴瓦 加厚1MM | LOWER BEARING SHELL U/S 1 |
| 10 | 30502-11-2959U/S1.5 | 下轴瓦 加厚1.5MM | LOWER BEARING SHELL U/S 1.5 |
| 11 | 30601-13HS-2573 | O 型圈 | O - RING |
| 12 | 30601-13HS-2751 | O 型圈 | O - RING |
| 13 | 30601-13HS-3007 | O型圈 | O-RING |
| 14 | 30601-13HS-3373 | O型圈 | O-RING |
| 15 | 30601-13HS-3375 | VALVE SPINDLE GUIDE INLET | VALVE SPINDLE GUIDE INLET |
| 16 | 30601-13HS-3376 | 阀杆 | VALVE SPINDLE GUIDE |
| 17 | 30601-13HS-4442 | 阀座 | VALVE SEAT RING EXHT. |
| 18 | 30601-13HS-4445 | 阀座 | VALVE SEAT RING INLET |
| 19 | 30701-15H-1098 | 镀铬活塞环 | CHROME-PLATED PISTON RING |
| 20 | 30701-15H-1187 | 活塞环 | PISTON RING |
| 21 | 30701-15H-1276 | 活塞环 | PISTON RING |
| 22 | 30701-15H-1365 | 刮油环 | SCRAPER RING |
| 23 | 30701-15H-1454 | 活塞 | PISTON |
| 24 | 30801-09H2-1681 | O 型圈 | O-RING |
| 25 | 30801-09H2-2115 | 垫片 | GASKET |
| 26 | 30801-10H1-0246 | 摇杆 | ROCKER ARM |
| 27 | 30801-10H1-2660 | 摇杆 | ROCKER ARM |
| 28 | 30801-10H1-4262 | 进气阀 (4CR9SIZ | INLET VALVE (4CR9SIZ) |
| 29 | 30801-10H1-5152 | 旋转阀 | VALVE ROTATOR |
| 30 | 30801-10H1-5518 | 排气阀 (23-8N) | OUTLET VALVE (23-8N) |
| 31 | 30801-10HI-3827 | 锥形圈 | CONICAL RING |
| 32 | 30801-10HI-5152 | VALVE ROTOR | VALVE ROTOR |
| 33 | 30901-12H-5571 | 密封圈 | SEALING RING FOR INLET |
| 34 | 30902-06H-1977 | GASKET EXHAUST MANIFOLD | GASKET EXHAUST MANIFOLD |
| 35 | 31001-09-1717 | 泵体 | PUMP HOUSING |
| 36 | 31001-11-1351 | GEAR RIM | GEAR RIM |
| 37 | 31001-11-2330 | O型圈 | O-RING |
| 38 | 31001-11-2429 | O型圈 | O-RING |

| | | | |
|----|-----------------|-----------------------------------|-----------------------------------|
| 39 | 31001-11H2-0461 | JOINT WASHER | JOINT WASHER |
| 40 | 31001-11H2-3045 | SECURING RING | SECURING RING |
| 41 | 31101-09H-0410 | 油嘴 | NOZZLE |
| 42 | 31101-09H-1211 | 垫片 | GASKET |
| 43 | 31101-09H-143 | FUEL V/V. COMPLETE | FUEL V/V. COMPLETE |
| 44 | 31102-01-1138 | 气缸床垫 | 气缸床垫 |
| 45 | 31102-01-1806 | 进油管接头 | 进油管接头 |
| 46 | 31502-09-0207 | 滑油滤芯总成 | LUB OIL FILTER COMPLETE |
| 47 | 31502-09-0485 | 滤芯 | FILTER ELEMENT 0485 |
| 48 | 31502-09-0663 | 密封圈 | SEALING RING 0663 |
| 49 | 31502-09H-0396 | SPACER RING | SPACER RING |
| 50 | 5T23LH-0108 | 活塞销 | PISTON PIN |
| 51 | 5T23LH-0475 | 衬套 | BUSH |
| 52 | 5T23LH-0564 | CHROME | CHROME |
| 53 | 5T23LH-0653 | 活塞环 | PISTON RING |
| 54 | 5T23LH-0742 | SCRAPPER RING | SCRAPPER RING |
| 55 | 5T23LH-0920 | 活塞 | PISTON |
| 56 | 5T23LH-1018 | STARTING VALVE, COMPLETE | STARTING VALVE, COMPLETE |
| 57 | 5T23LH-1138 | TIGHTENING RING | TIGHTENING RING |
| 58 | 5T23LH-1227 | 橡胶圈 | RUBBER RING |
| 59 | 5T23LH-1403 | 排气阀 | EXHAUST VALVE |
| 60 | 5T23LH-1588 | NOZZLE COMPLETE (COOLING TYPE) | NOZZLE COMPLETE (COOLING TYPE) |
| 61 | 5T23LH-1950 | VALVE GUIDE | VALVE GUIDE |
| 62 | 5T23LH-2395 | CYLINDER LINER | CYLINDER LINER |
| 63 | 5T23LH-2520 | COMPENSATOR | COMPENSATOR |
| 64 | 5T23LH-2607 | 密封圈 | PACKING RING |
| 65 | 5T23LH-2974 | GEAR RIM | GEAR RIM |
| 66 | 5T23LH-3005 | INLET VALVE | INLET VALVE |
| 67 | 246 | 摇臂 | 摇臂 |
| 68 | 337 | 垫片 | GASKET |
| 69 | 424 | 衬套(摇臂) | 衬套(摇臂) |
| 70 | 515 | 垫片 | GASKET |
| 71 | 604 | 示功阀 | 示功阀 |
| 72 | 762 | 垫片 | GASKET |
| 73 | 882 | 盖 | COVER |
| 74 | 971 | 螺钉 | SCREW |
| 75 | 1296 | 垫片 | GASKET |
| 76 | 1316 | 橡胶环 | RUBBER RING |
| 77 | 1474 | 起动阀总成 | STARTING V/V ASSY. |
| 78 | 1594 | 螺母 | NUT |
| 79 | 1609 | 膨胀节接头(接排气管) | 膨胀节接头(接排气管) |
| 80 | 1683 | 螺栓 | STUD |

| | | | |
|-----|--------------------|------------------------|------------------------|
| 81 | 1772 | O型圈?47X3.5 | O-RING?47X3.5 |
| 82 | 1855 | 垫片 | GASKET |
| 83 | 1950 | 阀导管 | VALVE GUIDE |
| 84 | 2028 | 螺母 | NUT |
| 85 | 20501-02-2684/2773 | 导向轴承 | Guide bearing |
| 86 | 2117 | 螺栓 | STUD |
| 87 | 2186 | 螺栓 | SCREW |
| 88 | 2206 | 螺栓 | STUD |
| 89 | 2660 | 摇臂 | 摇臂 |
| 90 | 2817 | 顶杆密封圈 | RUBBER SEAL, PUSH ROD |
| 91 | 2840 | 固定圈 | TIGHTENING RING |
| 92 | 2939 | 气缸套 | 气缸套 |
| 93 | 30502-14-2315 | 密封圈 | SEALING RING |
| 94 | 30502-14-3849 | 垫圈 | GASKET |
| 95 | 30502-14-3938 | 橡胶圈 | RUBBER RING |
| 96 | 30502-14-4006 | COOL.WATER CONNECTION. | COOL.WATER CONNECTION. |
| 97 | 30502-14-7776 | 橡胶圈 | RUBBER RING |
| 98 | 30502-14-7865 | COOL. WATER CONNECTION | COOL. WATER CONNECTION |
| 99 | 30502-14-7954 | 垫圈 | GASKET |
| 100 | 30502-16-4640 | O型圈 | O-ring |
| 101 | 30502-16-5352 | 垫片 | Gasket |
| 102 | 30502-16-6064 | 垫片 | Gasket |
| 103 | 30502-18H-1425 | O型圈 | O-RING |
| 104 | 30502-18H-3938 | 橡胶环 | RUBBER RING |
| 105 | 30502-18H-7776 | 橡胶环 | RUBBER RING |
| 106 | 30503-05-2928 | 定位销 | GUIDE PIN |
| 107 | 30503-05-3096 | 上盖 | COVER, UPPER PART |
| 108 | 30503-05-3185 | 下盖 | COVER, LOWER PART |
| 109 | 30503-05-3274 | 螺栓 | SCREW |
| 110 | 30503-05-3363 | 螺栓 | SCREW |
| 111 | 30601-03-0306 | 螺丝钉 | SCREW |
| 112 | 30601-03-0337 | 垫片 | GASKET |
| 113 | 30601-03-0515 | 垫片 | GASKET |
| 114 | 30601-03-1296 | 开口销 | SPLIT PIN |
| 115 | 30601-03-1316 | 橡胶环 | RUBBER RING |
| 116 | 30601-03-1861 | 垫片 | GASKET |
| 117 | 30601-05-2395 | 缸套 | CYL.LINER |
| 118 | 30601-08-2484 | 缸套 | CYLINDER LINER (NEW) |
| 119 | 30601-09-0159 | CLAMP | CLAMP |
| 120 | 30601-09-0248 | 示功阀 | INDICATOR VALVE |
| 121 | 30601-09-0604 | 气缸盖 | CYLINDER COVER |
| 122 | 30601-09-1049 | 阀座 | VALVE SEAT |

| | | | |
|-----|-----------------|---------------------------------------|--|
| 123 | 30601-09-1138 | 紧固环 | TIGHTENING RING |
| 124 | 30601-09-1861 | 垫圈 | GASKET |
| 125 | 30601-09-1950 | VALVE GUIDE | VALVE GUIDE |
| 126 | 30601-10-1683 | Ring Nut | Ring Nut |
| 127 | 30601-10-2573 | O 型圈 | O-ring |
| 128 | 30601-10-2751 | O 型圈 | O-ring |
| 129 | 30601-10-2840 | 垫圈 | GASKET |
| 130 | 30601-10-3829 | 垫圈 | GASKET |
| 131 | 30601-10-4442 | 阀座 | VALVE SEAT(OUTLET)D OUTSIDE 1-86.9;2-85.3mm |
| 132 | 30601-10-4531 | 阀座 | VALVE SEAT(INLET)D OUTSIDE 81mm |
| 133 | 30602-04-0762 | 垫片 | GASKET |
| 134 | 30602-04-1222 | 放气螺栓 | VENT SCREW |
| 135 | 30602-04-1296 | 垫片 | GASKET |
| 136 | 30602-04-2023 | 垫片 | GASKET |
| 137 | 30602-04-2186 | 螺栓 | SCREW |
| 138 | 30602-06H-0217 | 垫圈 | GASKET |
| 139 | 30602-06H-0306 | 垫圈 | GASKET |
| 140 | 30602-06H-0673 | 阀座 | VALVE SEAT |
| 141 | 30602-06H-1107 | 螺母 | NUT |
| 142 | 30602-07-0128 | Spindle | Spindle |
| 143 | 30602-07-0217 | 垫圈 | Gasket |
| 144 | 30602-07-0495 | 阀座 | Valve Seat |
| 145 | 30602-07H-0217 | 垫片 | GASKET |
| 146 | 30651-05-1222 | 放气螺丝 | VENT SCREW |
| 147 | 30651-05-1688 | SNAP-ON CONNECTOR,MALE COMPLETE | SNAP-ON CONNECTOR,MALE COMPLETE |
| 148 | 30651-05-2023 | 垫片 | GASKET |
| 149 | 30651-08-1400 | O 型圈 | O-ring with back up ring |
| 150 | 30652-07H1-0767 | 阀座研磨机 | GRINDING MACHINE FOR VALVE SEATS |
| 151 | 30701-09-0920 | 活塞 | PISTON |
| 152 | 30701-09-1454 | 连杆螺帽 | CASTLE NUT |
| 153 | 30701-09-1810 | 连杆螺栓 | CONNECTING ROD BOLT |
| 154 | 30701-11-0564 | 镀铬活塞环 | CHROME-PLATED PISTON RING |
| 155 | 30701-11-0653 | 活塞环 | PISTON RING |
| 156 | 30701-11-0742 | 刮油环 | SCRAPER RING |
| 157 | 30701-11-1365 | 开口销 | SPLIT SPIN |
| 158 | 30701-11-2156 | 开口销 | SPLIT SPIN |
| 159 | 30701-11-2166 | 开口销 | SPLIT PIN |
| 160 | 30701-14-0653 | 上轴瓦 | Bearing Shell Upper |
| 161 | 30701-14-0742 | 下轴瓦 | Bearing Shell Lower |

| | | | |
|-----|------------------------|---------------|---------------------------|
| 162 | 30701-14-1098 | 活塞环 | Piston ring |
| 163 | 30701-14-1810 | 连杆螺栓 | Connecting rod bolts |
| 164 | 30701-15H-1098 | 镀铬活塞环 | CHROME-PLATED PISTON RING |
| 165 | 30701-15H-1187 | 活塞环 | PISTON RING |
| 166 | 30701-15H-1276 | 活塞环 | PISTON RING |
| 167 | 30701-15H-1365 | 刮油环 | SCRAPER RING |
| 168 | 30701-17H-1454 | 活塞环组 | |
| 169 | 3074 | 顶杆胶圈 | 顶杆胶圈 |
| 170 | 30801-07-0791 | CYL.PIN 4X28 | CYL.PIN 4X28 |
| 171 | 30801-07-0979 | 弹性挡圈 | CIRCLIP |
| 172 | 30801-07-1047 | CON.RING 2/2 | CON.RING 2/2 |
| 173 | 30801-07-1225 | 内部弹簧 | SPRING INNER |
| 174 | 30801-07-1314 | SPRING PUTHER | SPRING PUTHER |
| 175 | 30801-07-2115/2204 | 垫片 | GASKET |
| 176 | 30801-07-2759 | ROTOCAP | ROTOCAP |
| 177 | 30801-09-0424 | 螺母 | NUT |
| 178 | 30801-09-0602 | THRUST SCREW | THRUST SCREW |
| 179 | 30801-09-1047 | CON. RING 2/2 | CON. RING 2/2 |
| 180 | 30801-09-1136 | SPRING DISC | SPRING DISC |
| 181 | 30801-09-1403 | 进气阀杆 | VALVE SPINDLE INLET |
| 182 | 30801-09-1592 | 手柄 | HANDLE |
| 183 | 30801-09-1681 | O型圈 | O-RING |
| 184 | 30801-09-1958 | 垫圈 | WASHER |
| 185 | 30801-09-2026 | 弹簧卡圈 | CIRCLIP |
| 186 | 30801-09-2115 | 垫圈 | GASKET |
| 187 | 30801-09-2759 | 旋阀器 | VALVE ROTATOR |
| 188 | 30801-09-3005 | VALVE SPINDLE | VALVE SPINDLE EXHAUST |
| 189 | 30801-09H2-1592 | 手柄 | HANDLE |
| 190 | 30801-09H2-1681 | O型圈 | O-RING |
| 191 | 30801-09H2-1958 | 衬套 | WASHER |
| 192 | 30801-09H2-2026 | 弹性挡圈 | CIRCLIP |
| 193 | 30801-09H2-2115 | 垫片 | GASKET |
| 194 | 30801-10-30801-10-4262 | Inlet Valve | Inlet Valve |
| 195 | 30801-10-3550 | 推力片 | Ball thrust piece |
| 196 | 30801-10-4262 | INLET VALVE | INLET VALVE |
| 197 | 30801-10-5518 | Outlet valve | Outlet valve |
| 198 | 30801-10-6686 | 推力片 | Ball thrust piece |
| 199 | 30802-03-2540 | THRUST PIECE | THRUST PIECE |
| 200 | 30802-03-2639 | 推杆 | PUSH ROD |
| 201 | 30802-03-2728 | THRUST PIECE | THRUST PIECE |
| 202 | 30802-03-2906 | TUBE | TUBE |
| 203 | 30802-04-0126 | 橡胶圈 | RUBBER RING |
| 204 | 30802-04-0304 | 密封圈 | SEALING RING |
| 205 | 30802-04-0671 | THRUST PIECE | THRUST PIECE |

| | | | |
|-----|----------------|-----------------|--------------------------|
| 206 | 30802-04-2273 | 销 | PIN |
| 207 | 30802-04-2362 | 衬套 | BUSH |
| 208 | 30802-04-2451 | SCREW | SCREW |
| 209 | 30802-04-2817 | 橡胶圈 | RUBBER RING |
| 210 | 30802-04-3074 | 橡胶圈 | RUBBER RING |
| 211 | 30802-04-3430 | ROLLER GUIDE | ROLLER GUIDE |
| 212 | 30802-04-3529 | STOP CREW | STOP CREW |
| 213 | 30802-04-3618 | ROLLER | ROLLER |
| 214 | 30802-05-0215 | 密封圈 | Sealing ring |
| 215 | 30802-05-1383 | 衬套 | Bush |
| 216 | 30802-05-1749 | Housing | Housing |
| 217 | 30802-05-3707 | 衬套 | Bush |
| 218 | 30802-08H-0126 | 橡胶环 | RUBBER RING |
| 219 | 30802-08H-2817 | 橡胶环 | RUBBER RING |
| 220 | 30802-4-0126 | 橡胶圈 | RUBBER RING |
| 221 | 30802-4-0304 | 密封圈 | SEALING RING |
| 222 | 30802-4-0760 | THRUST PIN | THRUST PIN |
| 223 | 30901-08-3054 | 螺栓 | SCREW |
| 224 | 30901-08-3232 | 垫片 | GASKET |
| 225 | 30901-10-2520 | 垫片 | GASKET |
| 226 | 30901-10-2708 | O型圈 | O- RING |
| 227 | 30901-12-5571 | 密封圈 | Sealing ring |
| 228 | 30902-05H-1977 | 垫片 | GASKET |
| 229 | 30902-05H-1978 | 垫片 | GASKET |
| 230 | 31001-03-0372 | 阀壳 | VLV HOUSING |
| 231 | 31001-03-0550 | 阀 | VALVE |
| 232 | 31001-03-0649 | 密封圈 | SEALING RING(COPPER) |
| 233 | 31001-03-0738 | 阀座 | VLV SEATS |
| 234 | 31001-03-1628 | 高压油泵壳体 | HOUSING FOR FUEL PUMP |
| 235 | 31001-03-2241 | 推力板 | THRUST PLATE |
| 236 | 31001-09-1084 | 导螺 | GUIDE SCREW |
| 237 | 31001-09-1173 | 坚固弹簧 | LOCKING SPRING |
| 238 | 31001-09-1262 | 放气螺丝 | VENT SCREW |
| 239 | 31001-09-1351 | 垫圈 | GASKET |
| 240 | 31001-09-1440 | 垫圈 | GASKET |
| 241 | 31001-09-1499 | NOZZLE UNCOOLED | NOZZLE UNCOOLED |
| 242 | 31001-09-1806 | 排气阀座 | DELIVERY VALVE HOUSING |
| 243 | 31001-09-2152 | 垫圈 | GASKET |
| 244 | 31001-09-2241 | 输油阀 | DELIVERY VALVE COMPLETE |
| 245 | 31001-09-2330 | 柱塞总成 | PLUNGER /BARREL ASSEMBLY |
| 246 | 31001-09-283 | 连轴器 | BANJO COUPLING |
| 247 | 31001-09-2974 | THRUST CAP | THRUST CAP |
| 248 | 31001-09-372 | 垫圈 | GASKET |
| 249 | 31001-09-916 | 垫圈 | GASKET |

| | | | |
|-----|---------------|-------------------------|--------------------------------|
| 250 | 31001-10-0194 | 燃油泵总成 | FUEL PUMP COMPLETE 0194 |
| 251 | 31001-10-2063 | 弹簧 | SPRING 2063 |
| 252 | 31001-10-2241 | DELIVERY VALVE,COMPLETE | DELIVERY VALVE,COMPLETE |
| 253 | 31001-10-2330 | 柱塞总成 | PLUNGER / BARREL ASSEMBLY 2330 |
| 254 | 31001-11-0372 | Plug Screw | Plug Screw |
| 255 | 31001-11-0461 | Joint Washer | Joint Washer |
| 256 | 31001-11-0550 | 柱塞总成 | Barrel / Plunger compl. |
| 257 | 31001-11-0649 | BARREL | BARREL |
| 258 | 31001-11-0738 | Non-Return Valve | Non-Return Valve |
| 259 | 31001-11-1084 | 螺丝 | Screw |
| 260 | 31001-11-1351 | GEAR RIM | GEAR RIM |
| 261 | 31001-11-1539 | 弹簧 | SPRING |
| 262 | 31001-11-1628 | LOWER SPRING PLATE | LOWER SPRING PLATE |
| 263 | 31001-11-1806 | O型圈 | O-RING |
| 264 | 31001-11-1995 | O型圈 | O-RING |
| 265 | 31001-11-2152 | 弹簧 | SPRING |
| 266 | 31001-11-2330 | O型圈 | O-RING |
| 267 | 31001-11-2429 | O型圈 | O-RING |
| 268 | 31001-11-2885 | 弹性挡圈 | Circlip |
| 269 | 31101-05-0143 | 管接头 | PIPE CONNECTION |
| 270 | 31101-05-0232 | 盖帽 | CAP NUT |
| 271 | 31101-05-0321 | 螺母 | NUT |
| 272 | 31101-05-0410 | 盖帽 | CAP NUT |
| 273 | 31101-05-0509 | 调节螺钉 | ADJUSTING SCREW |
| 274 | 31101-05-0698 | 弹簧 | SPRING |
| 275 | 31101-05-0787 | 推杆 | THRUST SPINDLE |
| 276 | 31101-05-0876 | 滤芯 | EDGE TYPE FILTER |
| 277 | 31101-05-0965 | 垫圈 | GASKET |
| 278 | 31101-05-1211 | 阀壳 | VALVE HOUSING |
| 279 | 31101-05-1677 | 接头 | UNION NUT |
| 280 | 31101-06-0143 | UNION | UNION |
| 281 | 31101-06-0232 | CAP NUT | CAP NUT |
| 282 | 31101-06-0321 | 螺母 | NUT |
| 283 | 31101-06-0410 | CAP NUT | CAP NUT |
| 284 | 31101-06-0509 | 调节螺钉 | ADJUSTING SCREW |
| 285 | 31101-06-0698 | 弹簧 | SPRING |
| 286 | 31101-06-0787 | THRUST SPINDLE | THRUST SPINDLE |
| 287 | 31101-06-0965 | 垫圈 | GASKET |
| 288 | 31101-06-1033 | 高压管 | HIGH-PRESSURE PIPE |
| 289 | 31101-06-1122 | 垫圈 | GASKET |
| 290 | 31101-06-1211 | VALVE HAUSING | VALVE HAUSING |
| 291 | 31101-06-1300 | O型圈 | O - RING |

| | | | |
|-----|--------------------------|-----------------|--|
| 292 | 31101-06-1499 | 油嘴总成(冷却型) | NOZZLE COMPLETE(COOLING TYPE) |
| 293 | 31101-06-1766 | 垫圈 | GASKET |
| 294 | 31101-06-1855 | O型圈 | O-RING |
| 295 | 31101-06-FUEL VALVE ASSY | FUEL VALVE ASSY | FUEL VALVE ASSY |
| 296 | 31101-06H-0143 | 接头 | UNION |
| 297 | 31101-06H-0321 | 螺母 | NUT |
| 298 | 31101-06H-0410 | 盖帽 | CAP NUT |
| 299 | 31101-06H-0509 | 调节螺钉 | ADJUSTING SCREW |
| 300 | 31101-06H-0698 | 弹簧 | SPRING |
| 301 | 31101-06H-0787 | 推杆 | THRUST SPINDLE |
| 302 | 31101-06H-1122 | 垫圈 | GASKET |
| 303 | 31101-06H-1300 | O型圈 | O-RING |
| 304 | 31101-06H-1766 | 垫圈 | GASKET |
| 305 | 31101-06H-1856 | 定位销 | GUIDE PIN |
| 306 | 31101-07-1033 | 高压油管 | HIGH PRESSURE PIPE 1033 |
| 307 | 31101-07-1211 | 喷油器 (冷却型) | VALVE HOUSING FOR FUEL VALVE UNCOOLED (COOLING TYPE) |
| 308 | 31101-07-1499 | 油嘴 (冷却型) | NOZZLE COMPLETE (COOLING TYPE) |
| 309 | 31101-07-1766 | 垫片 | GASKET |
| 310 | 31101-07H2-0143 | UNION | UNION |
| 311 | 31101-07H2-0232 | 盖母 | CAP NUT |
| 312 | 31101-07H2-0321 | 螺母 | NUT |
| 313 | 31101-07H2-0410 | | CAP UNIT |
| 314 | 31101-07H2-0509 | 调节螺栓 | ADJUSTING SCREW |
| 315 | 31101-07H2-0698 | 弹簧 | SPRING |
| 316 | 31101-07H2-0876 | 电子过滤器 | EDGE TYPE FILTER |
| 317 | 31101-07H2-1300 | O型圈 | O-RING |
| 318 | 31101-07H2-1766 | 垫片 | GASKET |
| 319 | 31101-09H-0410 | 油嘴 | NOZZLE |
| 320 | 31101-1499 | 冷却喷嘴 | NOZZLE-COOLING |
| 321 | 31101-1499-UC | 非冷喷嘴 | NOZZLE-UC |
| 322 | 31101-1855 | 定距块 | DISTANCE PIECE BETWEEN VALVE HOUSING&NOZZLE |
| 323 | 31101-1856 | 导销 | GUIDE PIN |
| 324 | 31201-07-0192 | COUPLING PART | COUPLING PART |
| 325 | 31308-01-0134 | 温度计 | THERMOMETER 50 - 600C |
| 326 | 31308-01-0401 | 压力计 | MANOMETER 0-6 BAR |
| 327 | 31308-01-0590 | 压力计 | MANOMETER 0-10 BAR |
| 328 | 31308-01-1391 | 温度计 | THERMOMETER 0-120 D.G. 1391 |
| 329 | 31308-01-1480 | 温度计罩 | THERMOMETER POCKET 1480 |

| | | | |
|-----|---------------|--------------------------------------|--------------------------------------|
| 330 | 31308-01-312 | 压力计 | MANOMETER 0-2,5 BAR |
| 331 | 31401-09-0190 | STARTING AIR DISTRIBUTOR COMPLETE | STARTING AIR DISTRIBUTOR COMPLETE |
| 332 | 31401-10-2336 | 活塞 | Valve piston |
| 333 | 31501-11-0126 | 橡胶圈 | RUBBER RING |
| 334 | 31501-11-0157 | ROCKER ARM , INT. COMPL. | ROCKER ARM , INT. COMPL. |
| 335 | 31501-11-0159 | CLAMP | CLAMP |
| 336 | 31501-11-0215 | COVER | COVER |
| 337 | 31501-11-0248 | INDICATOR VALVE | INDICATOR VALVE |
| 338 | 31501-11-0297 | 弹性挡圈 | CIRCLIP |
| 339 | 31501-11-0442 | 垫圈 | GASKET |
| 340 | 31501-11-0493 | SPRING GUIDE | SPRING GUIDE |
| 341 | 31501-11-0505 | 销 | PIN |
| 342 | 31501-11-0509 | 调节螺钉 | ADJUSTING SCREW |
| 343 | 31501-11-0582 | 弹簧 | SPRING |
| 344 | 31501-11-0671 | THRUST PIECE | THRUST PIECE |
| 345 | 31501-11-0694 | SOCKET | SOCKET |
| 346 | 31501-11-0698 | 弹簧 | SPRING |
| 347 | 31501-11-0783 | 球轴承 | BALL BEARING |
| 348 | 31501-11-0791 | CYL. PIN | CYL. PIN |
| 349 | 31501-11-0872 | 弹性挡圈 | CIRCLIP |
| 350 | 31501-11-0880 | BRACKET | BRACKET |
| 351 | 31501-11-0961 | COG WHEEL | COG WHEEL |
| 352 | 31501-11-1039 | 垫圈 | GASKET |
| 353 | 31501-11-1047 | CON. RING 2/2 | CON. RING 2/2 |
| 354 | 31501-11-1049 | 排气阀座 | VALVE SEAT EXH. |
| 355 | 31501-11-1049 | 进气阀座 | VALVE SEAT INT. |
| 356 | 31501-11-1122 | 垫圈 | GASKET |
| 357 | 31501-11-1128 | COVER | COVER |
| 358 | 31501-11-1136 | SPRING DISK | SPRING DISK |
| 359 | 31501-11-1138 | TIGHTENING RING | TIGHTENING RING |
| 360 | 31501-11-1217 | SCREW | SCREW |
| 361 | 31501-11-1227 | 密封圈 | SEALING RING |
| 362 | 31501-11-1294 | THRUST WASHER (A, B, C | THRUST WASHER (A, B, C) |
| 363 | 31501-11-1300 | O型圈 | O-RING |
| 364 | 31501-11-1365 | 开口销 | SPLIT PIN |
| 365 | 31501-11-1405 | LINER F. FUEL VALVE | LINER F. FUEL VALVE |
| 366 | 31501-11-1454 | CASTLE NUT | CASTLE NUT |
| 367 | 31501-11-1499 | 油嘴 | NOZZLE , COMPL. |
| 368 | 31501-11-1613 | 橡胶圈 | RUBBER RING |
| 369 | 31501-11-1681 | O型圈 | O-RING |
| 370 | 31501-11-1721 | GUIDE PIN | GUIDE PIN |
| 371 | 31501-11-1762 | 键 | KEY |

| | | | |
|-----|---------------|-------------------------------|-----------------------------|
| 372 | 31501-11-1766 | 垫圈 | GASKET |
| 373 | 31501-11-1792 | 垫圈 | GASKET |
| 374 | 31501-11-1810 | 连杆螺栓 | CONNECTION ROD BOLT |
| 375 | 31501-11-1851 | 衬套 | BUSH |
| 376 | 31501-11-1861 | 垫圈 | GASKET |
| 377 | 31501-11-1958 | 垫圈 | WASHER |
| 378 | 31501-11-1995 | THRUST WASHER | THRUST WASHER |
| 379 | 31501-11-2026 | 弹性挡圈 | CIRCLIP |
| 380 | 31501-11-2063 | 弹簧 | SPRING |
| 381 | 31501-11-2077 | SCREW | SCREW |
| 382 | 31501-11-2107 | END COVER | END COVER |
| 383 | 31501-11-2115 | 垫圈 | GASKET |
| 384 | 31501-11-2152 | 垫圈 | GASKET |
| 385 | 31501-11-2166 | SPLIT PIN | SPLIT PIN |
| 386 | 31501-11-2241 | DELIVERY VALVE , COMPL. | DELIVERY VALVE , COMPL. |
| 387 | 31501-11-2296 | COG WHEEL | COG WHEEL |
| 388 | 31501-11-2315 | 密封圈 | SEALING RING |
| 389 | 31501-11-2330 | 柱塞 | PLUNGER / BARREL / ASSEMBLY |
| 390 | 31501-11-2385 | CIRCLIP | CIRCLIP |
| 391 | 31501-11-2395 | SPRING PIN | SPRING PIN |
| 392 | 31501-11-2474 | SHAFT W. GEAR WHEEL ,LONG | SHAFT W. GEAR WHEEL ,LONG |
| 393 | 31501-11-2482 | ROCKER ARM , EXH. COMPL. | ROCKER ARM , EXH. COMPL. |
| 394 | 31501-11-2484 | SPRING PIN | SPRING PIN |
| 395 | 31501-11-2518 | SPRING PLATE UPPER | SPRING PLATE UPPER |
| 396 | 31501-11-2520 | 垫圈 | GASKET |
| 397 | 31501-11-2540 | THRUST PIECE | THRUST PIECE |
| 398 | 31501-11-2563 | SHAFT W. GEAR WHEEL ,SHORT | SHAFT W. GEAR WHEEL ,SHORT |
| 399 | 31501-11-2571 | 轴 | SHAFT |
| 400 | 31501-11-2607 | 锁紧圈 | LOCK RING |
| 401 | 31501-11-2639 | 推杆 | PUSH ROD |
| 402 | 31501-11-2708 | O型圈 | O-RING |
| 403 | 31501-11-2728 | THRUST PIECE | THRUST PIECE |
| 404 | 31501-11-2759 | VALVE ROTATOR | VALVE ROTATOR |
| 405 | 31501-11-2796 | 弹簧 | SPRING |
| 406 | 31501-11-2817 | 橡胶圈 | RUBBER RING |
| 407 | 31501-11-2906 | TUBE | TUBE |
| 408 | 31501-11-2974 | THRUST CAP | THRUST CAP |
| 409 | 31501-11-2986 | 垫圈 | GASKET |
| 410 | 31501-11-3027 | 销 | PIN |
| 411 | 31501-11-3042 | 弹性挡圈 | CIRCLIP |

| | | | |
|-----|---------------------------------------|------------------------------|---------------------------------------|
| 412 | 31501-11-3074 | 橡胶圈 | RUBBER RING |
| 413 | 31501-11-3116 | SCREW | SCREW |
| 414 | 31501-11-3252 | 弹簧 | SPRING |
| 415 | 31501-11-3321 | 垫圈 | GASKET |
| 416 | 31501-11-3341 | THRUST PIECE | THRUST PIECE |
| 417 | 31501-11-3849 | 垫圈 | GASKET |
| 418 | 31501-11-3938 | 橡胶圈 | RUBBER RING |
| 419 | 31501-11-4006 | COOL WATER CONNECTION | COOL WATER CONNECTION |
| 420 | 31501-11-5122 | OVERSPEED TRIP | OVERSPEED TRIP |
| 421 | 31501-11-7776 | 橡胶圈 | RUBBER RING |
| 422 | 31501-11-7865 | COOL WATER CONNECTION | COOL WATER CONNECTION |
| 423 | 31501-11-7954 | 垫圈 | GASKET |
| 424 | 31501-11-LUBRICATING OIL PUMP(COMPL.) | LUBRICATING OIL PUMP(COMPL.) | LUBRICATING OIL PUMP(COMPL.) |
| 425 | 31502-09-00485 | 滤心 | FILTER ELEMENT 00485 |
| 426 | 31502-09-0485 | 滤芯 | FILTER ELEMENT 0485 |
| 427 | 31502-09-0663 | 密封圈 | SEALING RING 0663 |
| 428 | 31502-09-0841 | 密封圈 | SEALING RING 0841 |
| 429 | 31601-05-1800 | COUPLIN | COUPLIN |
| 430 | 31601-05-2067 | BACK UP RING | BACK UP RING |
| 431 | 31601-05-2156 | 密封圈 | SEALING RING |
| 432 | 31701-01-0503 | 螺母 | NUT 0503 |
| 433 | 31701-01-0692 | 叶轮 | IMPELLER 0692 |
| 434 | 31701-01-1215 | 轴 | SHAFT 1215 |
| 435 | 3283 | 阀桥 | 阀桥 |
| 436 | 3824 | 长套(气门锁共) | 长套(气门锁共) |
| 437 | 3902-01-0808 | 螺栓 | SCREW |
| 438 | 3902-01-1510 | 垫片 | GASKET |
| 439 | 3902-1-0808 | 不锈钢螺栓 | SCREW |
| 440 | 3902-1-1510 | 垫片 | GASKET |
| 441 | 4351 | 衬套(摇臂) | 衬套(摇臂) |
| 442 | 6042 | 缸头垫片 | GASKET,HEAD COVER |
| 443 | 6T23LH-DISTANCE PIECE BET.V/ | 隔离块 | DISTANCE PIECE BET.V/VHOUSING& NOZZLE |
| 444 | 6T23LH-GUIDE PIN | 导销 | GUIDE PIN |
| 445 | 6T23LH-NOZZLE | 油嘴(非冷) | NOZZLE(UNCOOLING) |
| 446 | T23L-0859 | ROLLER GUIDE | ROLLER GUIDE |
| 447 | T23L-0948 | 销 | PIN |
| 448 | T23L-1105 | 衬套 | BUSH |
| 449 | T23L-1561 | ROLLER | ROLLER |
| 450 | THERMOMETER 50-650 D.G. | 温度计 | THERMOMETER 50-650 D.G. |

| | | | |
|-----|-----------------------------|--|--|
| 451 | 1031 | 螺母 | NUT |
| 452 | 1219 | 销 | PIN |
| 453 | 1260 | 齿轮 | GEAR WHEEL |
| 454 | 1308 | 齿轮 | GEAR |
| 455 | 1497 | 衬套 | BUSH |
| 456 | 1586 | 齿轮 | GEAR |
| 457 | 2298 | 垫圈 | WASHER |
| 458 | 2387 | 推力瓦 | THRUST BEARING |
| 459 | 2476 | 齿轮 | GEAR |
| 460 | 2654 | 螺母 | NUT |
| 461 | 30601-10-0604 | 示功阀 | INDICATOR VALVE |
| 462 | 30601-10-0882 | CONNECTING PIECE | CONNECTING PIECE |
| 463 | 30601-10-2117 | O 型圈 | O RING |
| 464 | 30601-10-2662 | PIPE | PIPE |
| 465 | 30601-10-2840 | 垫圈 | GASKET |
| 466 | 30601-10-2939 | 缸套 | CYLINDER LINER |
| 467 | 30601-10-3374 | 阀杆导套 | VALVE SPINDLE GUIDE (CYLINDER UNIT PLATE NO.: 30601-10) |
| 468 | 30601-10-3829 | 垫片 | GASKET |
| 469 | 30601-10-4442 | 阀座 | VALVE SEAT(OUTLET)D OUTSIDE 1-86.9;2-85.3mm |
| 470 | 30601-10-4531 | 阀座 | VALVE SEAT(INLET)D OUTSIDE 81mm |
| 471 | 30701-14-1187 | 活塞环 | PISTON RING(PISTON AND CONNECTING ROAD PLATE NO.:30701-14) |
| 472 | 30701-14-1276 | 活塞环 | PISTON RING |
| 473 | 30701-14-1365 | SCRAPPER RING | SCRAPPER RING |
| 474 | 30701-14-1454 | 活塞 | PISTON |
| 475 | 30801-10-2026 | O型圈 | O RING |
| 476 | 30801-10-4262 | INLET VALVE | INLET VALVE |
| 477 | 30801-10-5152 | VALVE ROCATOR | VALVE ROCATOR |
| 478 | 30801-10-5518-DIESEL OIL | OUTLET VALVE(VALVE GEAR PLATE NO.:30801-10) | OUTLET VALVE(VALVE GEAR PLATE NO.:30801-10) |
| 479 | 30801-10-5518-HEAVY OIL | OUTLET VALVE(VALVE GEAR PLATE NO.:30801-10) | OUTLET VALVE(VALVE GEAR PLATE NO.:30801-10) |
| 480 | 30801-10-5885 | O型圈 | O RING |
| 481 | 30801-10-6042 | GASKET | GASKET |
| 482 | 30802-05-0304 | O型圈 | O RING |
| 483 | 30802-05-2273 | THRUST PIECE | THRUST PIECE |
| 484 | 30802-05-2451 | THRUST PIECE | THRUST PIECE |
| 485 | 30802-05-2540 | O 型圈 | O RING(VALVE GEAR PLATE NO.:30802-05) |

| | | | |
|-----|---------------------|--|--|
| 486 | 30802-05-2817 | O型圈 | O RING |
| 487 | 30802-05-3341 | THRUST PIECE | THRUST PIECE |
| 488 | 30902-03H-1977 | 垫圈 | GASKET(EXHAUST PIPE ARRANGEMENT PLATE NO.:30902-03H) |
| 489 | 31101-08-0410 | 油嘴总成(FUEL VALVE PLATE NO.:31101-08) | NOZZLE COMPLETE(FUEL VALVE PLATE NO.:31101-08) |
| 490 | 31101-08-0787 | 弹簧 | SPRING |
| 491 | 31101-08-1033 | O 型圈 | O RING |
| 492 | 31102-01-0112 | 高压油管 | HIGH PRESSURE PIPE |
| 493 | 31102-01-1468 | O 型圈 | O-RING |
| 494 | 31103-01L-0101 | 高压油管 | HIGH PRESSURE FUEL PIPE ,MAN(PLATE NO.:31103-01L) |
| 495 | 30502-13-2771+2959 | 主轴瓦 | MAIN BEARING SHELL UPPER+LOWER |
| 496 | 30502-20H1-3027 | 密封圈 | SEALING RING |
| 497 | 30502-20H1-3225 | 锁片 | LOCKING PLATE |
| 498 | 30503-05-1049 | 阀座 | VALVE SEAT |
| 499 | 30504-07-0395 | 曲轴 | CRANKSHAFT |
| 500 | 30601-07C-1138 | 锁紧环 | TIGHTENING RING |
| 501 | 30601-07C-1227 | 上橡胶圈 | RUBBER RING LOWER |
| 502 | 30601-07C-2396 | 下橡胶圈 | RUBBER RING UPPER |
| 503 | 30701-09-1543+1632 | 连杆瓦 | CON ROD BEARING SHELL UPPER+LOWER |
| 504 | 30701-09A-108 | 活塞销 | PISTON PIN |
| 505 | 30701-09A-1098 | 集油器 | OIL COLLECTOR |
| 506 | 30701-09A-1543 | 上轴瓦 | UPPER BEARING SHELL |
| 507 | 30701-09A-1632 | 下轴瓦 | LOWER BEARING SHELL |
| 508 | 30701-09A-1810&1454 | 连杆螺栓和螺母 | CONNECTING ROD BOLTS & CASTLE NUTS |
| 509 | 30701-09A-2255 | SCRAPPER RING | SCRAPPER RING |
| 510 | 30701-09A-564 | 活塞环镀铬 | CHROME PLATED PISTON RING |
| 511 | 30701-09A-653 | 活塞环 | PISTON RING |
| 512 | 30701-09A-742 | SCRAPPER RING | SCRAPPER RING |
| 513 | 30801-07-1403 | 排气阀 | OUTLET VALVE |
| 514 | 30801-07-157 | 摇臂进口总成 | ROCKER ARM INLET COMPLETE |
| 515 | 30801-07-2115 | 垫圈 | GASKET |
| 516 | 30801-07-2204 | 垫圈 | GASKET |
| 517 | 30801-07-2482 | 摇臂出口总成 | ROCKER ARM EXH. COMPLETE |
| 518 | 30901-06A-740 | 补偿器 | COMPENSATOR |
| 519 | 31001-03-0372 | 阀壳 | VLV HOUSING |
| 520 | 31001-03-0550 | 阀 | VALVE |
| 521 | 31001-03-0649 | 密封圈 (铜) | SEALING RING(COPPER) |
| 522 | 31001-03-0738 | 阀座 | VLV SEATS |

| | | | |
|-----|----------------|--------------------------------|--|
| 523 | 31001-03-2241 | 推力板 | THRUST PLATE |
| 524 | 31001-0649 | 柱塞 | PLANGER AND BARREL WITH NON RETURN V/V COMPLETE |
| 525 | 31101-09H-0410 | 油嘴 | NOZZLE |
| 526 | 31305-11H-1106 | FLYWEIGHT | FLYWEIGHT |
| 527 | 31305-11H-1473 | 球轴承 | BALL BEARING |
| 528 | 31305-11H-1562 | 弹性联轴器 | RESILIENT COUPLING |
| 529 | 31305-11H-1839 | 柱塞 | SCREW |
| 530 | 31305-11H-2363 | 弹簧 | SPRING |
| 531 | 31305-11H-2818 | 杆 | LEVER |
| 532 | 31305-11H-3075 | FLYWEIGHT HOUSING | FLYWEIGHT HOUSING |
| 533 | 31305-11H-3253 | 调节螺栓 | ADJUSTING SCREW |
| 534 | 31305-11H-3342 | 调节器弹簧 | GOVERNOR SPRING |
| 535 | 31305-11H-3431 | 键 | KEY |
| 536 | 31305-11H-3520 | 球轴承 | BALL BEARING |
| 537 | 31305-11H-3897 | 轴 | SPINDLE |
| 538 | 31305-11H-3986 | 弹簧 | SPRING |
| 539 | 31305-11H-4698 | 弹簧 | SPRING |
| 540 | 31305-11H-4876 | 弹簧 | SPRING |
| 541 | 31305-11H-5122 | 阀 | VALVE |
| 542 | 31305-11H-583 | 杆 | LEVER |
| 543 | 31502-09-0485 | 滤芯 | FILTER ELEMENT 0485 |
| 544 | 31602-09H-0256 | 滤芯 | FILTER ELEMENT |
| 545 | T23LH-1561 | ROLLER | ROLLER |
| 546 | T23L-0161 | 螺钉 | SCREW |
| 547 | T23L-0349 | 衬套 | BUSH |
| 548 | T23L-0527 | 齿轮 | GEAR WHEEL |
| 549 | T23L-0760 | THRUST PIN | THRUST PIN |
| 550 | T23L-0859 | ROLLER GUIDE | ROLLER GUIDE |
| 551 | T23L-0894 | 介轮,PLATE 31202-05GEAR WHEEL | INTERMEDIATE WHEEL,PLATE 31202-05GEAR WHEEL |
| 552 | T23L-0948 | 销 | PIN |
| 553 | T23L-1051 | 螺母 | NUT |
| 554 | T23L-1105 | 衬套 | BUSH |
| 555 | T23L-1276 | 活塞 | PISTON (NEW TYPE) |
| 556 | T23L-1561 | ROLLER | ROLLER |
| 557 | T23L-1829 | 曲轴,PLATE30504-07GEAR WHEEL | CRANK SHAFT,PLATE30504- 07GEAR WHEEL |
| 558 | T23L-ROTOCAP | 旋阀器 | ROTOCAP |
| 559 | T23LH-0760 | THRUST PIN | THRUST PIN |