

SULZER (RTA58)

ITEM	PART NO.	中文名称	ENGLISH DESCRIPTION
1	5RTA58-U27106	弹性螺栓	ELASTIC STUD FOR RELIEF
2	5RTA58-U27107	弹性螺栓	ELASTIC STUD FOR STARTING AIR VALVE
3	5RTA58-U27113	螺旋塞	SCREW PLUG FOR CYLINDER COVER
4	5RTA58-U27114	螺旋塞	SCREW PLUG FOR CYLINDER COVER
5	5RTA58-U27115	JOINT RING FOR SCREW PLUG	JOINT RING FOR SCREW PLUG
6	5RTA58-U27121	JOINT RING FOR SCREW PLUG	JOINT RING FOR SCREW PLUG
7	5RTA58-U27222	套筒扳手头阀	SOCKET HEAD VALVE FOR FUEL INJECTION VALVE
8	5RTA58-U27224	O型圈	O RING FOR NOZZLE HOLDER U27201
9	5RTA58-U27226	O型圈	O RING FOR CIRCULATION V/VU27215
10	5RTA58-U27227	O型圈	O RING FOR SPRING TENSIONER
11	5RTA58-U27240	油嘴	NOZZLE WITH NEEDLE FOR FUEL INJECTION VALVE ONE PIECE (0.775/0.75/0.725/0.625/0C7R0
12	6RTA58-U21410	缸头与缸套间垫片	JOINT RING ON CYLINDER LINER
13	6RTA58-U21411	水导套橡皮圈(内径800*粗 9)	O RING(800*9)
14	6RTA58-U23101	SCRAPER RING IN 3 PARTS	SCRAPER RING IN 3 PARTS
15	6RTA58-U23102	SEALING RING IN 3 PARTS	SEALING RING IN 3 PARTS
16	6RTA58-U23120	刮油环	OIL SCRAPER RING IN 3 PARTS WITH PIN COMPLETE
17	6RTA58-U23125	活塞杆填料函弹簧	SPRING, STUFFING BOX
18	6RTA58-U23126	活塞杆填料函弹簧	SPRING, STUFFING BOX
19	6RTA58-U23128	O型圈	O RING FOR UPPER HOUSING U23112
20	6RTA58-U23130	O型圈	O-RING FOR LOWER HOUSING
21	6RTA58-U27101	缸盖	CYLINDER COVER
22	6RTA58-U27202	HOUSING FOR FUEL INJECTION VALVE	HOUSING FOR FUEL INJECTION VALVE
23	6RTA58-U27211	弹簧座	SPRING SEAT
24	6RTA58-U27429	O型圈	O-RING FOR HOUSING U27404
25	6RTA58-U27430	O型圈	O-RING FOR HOUSING U27404

26	6RTA58-U27431	JOINT RING FOR VALVE SEAT U27414	JOINT RING FOR VALVE SEAT U27414
27	6RTA58-U27510	橡皮圈	O RING
28	6RTA58-U27548	杆用密封圈	ROD JOINT RING FOR VALVE SPINDLE
29	6RTA58-U27550	橡皮圈	O RING
30	6RTA58-U27701	HOUSING FOR RELEIF VALVE	HOUSING FOR RELEIF VALVE
31	6RTA58-U27704	张紧轮	SPRING TENSIONER FOR RELIEF VALVE
32	6RTA58-U27706	弹簧座	SPRING CARRIER FOR RILIEF VALVE
33	6RTA58-U27707	压缩弹簧	COMPRESSION SPRING FOR RELIEF VALVE
34	6RTA58-U27709	定距环	DISTANCE RING FOR RELIEF VALVE
35	6RTA58-U27710	O型圈	O-RING FOR RELIEF VALVE
36	6RTA58-U27712	接头	JOINT FOR VALVE SEAT U27702
37	6RTA58-U27721	示功阀	INDICATOR VALVE
38	6RTA58-U27723	法兰	FLANGE FOR INDICATOR VALVE
39	6RTA58-U34002	螺母	NUT FOR ELASTICSTUD U34107
40	6RTA58-U34126	活塞裙	PISTON SKIRT COMPLETE
41	6RTA58-U34230	RUNNING PIPE OR PISTON	RUNNING PIPE OR PISTON
42	6RTA58-U34407	活塞环	PISTON RING(KO.H1)12MM
43	6RTA58-U34408	活塞环	PISTON RING KO.H1=12MM
44	6RTA58-U34409	活塞环	PISTON RING(KOP.H2)16MM
45	6RTA58-U36160	活塞冷却水进水拉管组件 (包括: 喷嘴/导套/进水立管/间隔管/导套/止动垫圈)	Stand pipe for piston cooling-intlet Complete
46	6RTA58-U36163	GUIDE BUSH FOR STAND PIPE	GUIDE BUSH FOR STAND PIPE
47	6RTA58-U36167	GUIDE BUSH FOR STAND INLET	GUIDE BUSH FOR STAND INLET
48	6RTA58-U36171	O型圈	UPPER O-RING FOR SRAND PIPE(IN&OUT)
49	6RTA58-U36172	O型圈	LOWER O-RING FOR STAND PIPE(IN&OUT)
50	6RTA58-U36175	活塞冷却水出水拉管组件 (包括: 导套/出水立管/间隔管/导套/止动垫圈/出水喷嘴)	Stand pipe for piston cooling-outlet Complete
51	6RTA58-U36203	SCRAPER RING ON GLAND BOX	SCRAPER RING ON GLAND BOX

52	6RTA58-U36210	活塞水填料函刮油环弹簧	SPRING, OIL SCRAPER, STUFFING BOX
53	6RTA58-U36211	活塞水填料函导环弹簧	SPRING, STUFFING BOX
54	6RTA58-U36216	O型圈	O-RING FOR RING HOLDER
55	6RTA58-U53205	二位三通电磁阀	二位三通电磁阀
56	7RTA58-U27116	ROUND RUBBER COVER	ROUND RUBBER COVER
57	7RTA58-U27523	扣环	RETAINING RING FOR
58	7RTA58-U27530	扣环	RETAINING RING FOR BUSH
59	7RTA58-U27549	O型圈	O RING
60	7RTA58-U27721	示功阀	INDICTATOR VALVE
61	7RTA58-U34003	锁闭圆盘	Locking disc for nut u 34002
62	7RTA58-U34107	弹性柱头螺栓	Elastic stud on piston without nuts
63	7RTA58-U34401	活塞环	PISTON RING
64	7RTA58-U36207	CLAMP ON GLAND BOX	CLAMP ON GLAND BOX
65	RTA58-00011103-03	温度计	THERMOMETER FOR CYLINDER COOLING OUTLET 0-100DEG. C D=M20X1.5,L=55MM
66	RTA58-00011103-04	温度计	THERMOMETER FOR F.O. INLET 0-200 DEG.C D=M20X1.5,L=80MM
67	rta58-27221	COMPRESSION FOR FUEL INJ.VALVE	COMPRESSION FOR FUEL INJ.VALVE
68	RTA58-94215	活塞杆密封环	ROD SEAL RING
69	RTA58-U21111	环	WATER GUIDE RING FOR CYLINDER JACKET
70	RTA58-U21112	橡胶圈	ROUND RUBBER RING FOR
71	RTA58-U21300	WATER GUIDE JACKET FOR CYLINDER LINER	WATER GUIDE JACKET FOR CYLINDER LINER
72	RTA58-U21400	缸套	CYLINDER LINER, COMPLETE (U21401-U21412
73	RTA58-U21401	缸套	CYLINDER LINER
74	RTA58-U21406	垫片	FILLING PIECE ON CYLINDER LINER
75	RTA58-U21407	JOINT FOR FILLING PIECE	JOINT FOR FILLING PIECE
76	RTA58-U21410	JOINT RING ON CYLINDER LINER	JOINT RING ON CYLINDER LINER
77	RTA58-U21411	橡胶圈	RUBBER RING FOR WATER GUIDE JACKET
78	RTA58-U21412	橡胶圈	RUBBER RING FOR CYLINDER LINER
79	RTA58-U23113	刮油环	OIL SCRAPER RING,IN THREE PARTS,COMPLETE
80	RTA58-U23114	刮油环	OIL SCRAPER RING,IN THREE PARTS,COMPLETE(WITH SPRING DOWEL PIN)

81	RTA58-U23119	刮油环	OIL SCRAPER RING , COMPL.
82	RTA58-U23129	O 型圈	O-RING FOR RING HOLDER
83	RTA58-U27105	SLEEVE FOR CYLINDER COVER	SLEEVE FOR CYLINDER COVER
84	RTA58-U27116	圆橡胶盖	ROUND RUBBER COVER
85	RTA58-U27203	STOP BUSH FOR FUEL INJECTION VALVE	STOP BUSH FOR FUEL INJECTION VALVE
86	RTA58-U27204	GUIDE BUSH FOR FUEL INJECTION VALVE	GUIDE BUSH FOR FUEL INJECTION VALVE
87	RTA58-U27205	WASHER FOR FUEL INJECTION VALVE	WASHER FOR FUEL INJECTION VALVE
88	RTA58-U27208	DISC SPRING FOR FUEL INJECTION VALVE	DISC SPRING FOR FUEL INJECTION VALVE
89	RTA58-U27209	SNAP RING FOR HOUSING	SNAP RING FOR HOUSING
90	RTA58-U27210	阀杆	SPINDLE FOR FUEL INJECTION VALVE
91	RTA58-U27215	环流阀	CIRCULATION VALVE FOR FUEL INJECTION VALVE
92	RTA58-U27216	NEEDLE SEAT NEEDLE FOR CIRCULATION VALVE	NEEDLE SEAT NEEDLE FOR CIRCULATION VALVE
93	RTA58-U27224	O 型圈	O-RING FOR HOUSING FOR FUEL INJECTION VALVE
94	RTA58-U27224	O 型圈	O-RING FOR HOUSING FOR FUEL INJECTION
95	RTA58-U27225	O 型圈	O RING FOR COLLAR NUTU 27214
96	RTA58-U27226	O 型圈	O-RING FOR CIRCULATION VALVE U27215
97	RTA58-U27227	O 型圈	ORING FOR SPRING TENSIONER U27212
98	RTA58-U27242	NOZZLE BODY WITH NEEDEL FOR FUEL INJECTI	NOZZLE BODY WITH NEEDEL FOR FUEL INJECTION VALVE(SEALING SURFACE IS
99	RTA58-U27408	VALVE SPRINDLE FOR STARTING AIR VALVE	VALVE SPRINDLE FOR STARTING AIR VALVE
100	RTA58-U27424	活塞环	PISTON RING FOR STARTING AIR VALVE
101	RTA58-U27425	活塞环	PISTON RING FOR STARTING AIR VALVE
102	RTA58-U27426	活塞环	PISTON RING FOR STARTING AIR VALVE
103	RTA58-U27427	杆用密封圈	ROD SEAL RING FOR BUSH
104	RTA58-U27508	排气阀座	EXHAUST VALVE SEATS
105	RTA58-U27510	O 型圈	O-RING FOR VALVE SEAT

106	RTA58-U27514	UPPER HOUSING TO EXHAUST VALVE	UPPER HOUSING TO EXHAUST VALVE
107	RTA58-U27517	HOUSING TO VALVE DRIVE	HOUSING TO VALVE DRIVE
108	RTA58-U27518	排气阀	EXHAUST VALVE SPINDLES
109	RTA58-U27522	导管衬套	GUIDE BUSH FOR VALVE
110	RTA58-U27523	RETAINING RING FOR EXH.VALVE	RETAINING RING FOR EXH.VALVE
111	RTA58-U27524	缸套	CYLINDER FOR EXHAUST VALVE
112	RTA58-U27525	DISTANCE SLEEVE FOR EXHAUST VALVE	DISTANCE SLEEVE FOR EXHAUST VALVE
113	RTA58-U27526	螺母	NUT FOR VALVE SPINDLE
114	RTA58-U27530	RETAINING RING FOR BUSH	RETAINING RING FOR BUSH
115	RTA58-U27531	PRESSURE PLATE FOR SLEEVE U27528	PRESSURE PLATE FOR SLEEVE U27528
116	RTA58-U27532	活塞	PISTON TO VALVE DRIVE
117	RTA58-U27533	DAMPING ELEMENT TO VALVE DRIVE	DAMPING ELEMENT TO VALVE DRIVE
118	RTA58-U27535	LOCKING RING TWO PARTS FOR VALVE SPINDLE	LOCKING RING TWO PARTS FOR VALVE SPINDLE
119	RTA58-U27537	VENT HOUSING FOR VALVE DRIVE	VENT HOUSING FOR VALVE DRIVE
120	RTA58-U27538	SEALING AIR THROTTLE COMPL. FOR EXH. V/V	SEALING AIR THROTTLE COMPL. FOR EXH. V/V
121	RTA58-U27539	JOINT RING FOR SEALING AIR THROTTLE U27538	JOINT RING FOR SEALING AIR THROTTLE U27538
122	RTA58-U27546	活塞环	PISTON RING WITH GASTIGHT SNAP FOR PISTON U27532
123	RTA58-U27547	活塞连接环	PISTON JOINT RING FOR AIR CYL.HOUSING U27511
124	RTA58-U27548	ROD JOINT RING FOR VALVE SPINDLE	ROD JOINT RING FOR VALVE SPINDLE
125	RTA58-U27549	O型圈	O RING
126	RTA58-U27552	O型圈	O-RING FOR BUSH U 27529
127	RTA58-U27554	O型圈	O-RING FOR VENTHOUSING U27537
128	RTA58-U27555	JOINT RING FOR VALVE SEAT U27508	JOINT RING FOR VALVE SEAT U27508
129	RTA58-U27560	JOINT RING FOR SCREW PLUG U27579	JOINT RING FOR SCREW PLUG U27579
130	RTA58-U27561	JOINT RING FOR SCREW PLUG U27580	JOINT RING FOR SCREW PLUG U27580

131	RTA58-U27562	JOINT RING FOR VENTHOUSING U27537	JOINT RING FOR VENTHOUSING U27537
132	RTA58-U27563	弹簧	DISC SPRING FOR RETAINING RING
133	RTA58-U27564	拉伸弹簧	TENSION SPRING FOR LOCKING RING
134	RTA58-U27565	SHIM RING FOR DAMPING ELEMENT U27533	SHIM RING FOR DAMPING ELEMENT U27533
135	RTA58-U27579	螺旋塞	SCREW PLUG FOR VENTHOUSING U27537
136	RTA58-U27580	螺旋塞	SCREW PLUG FOR HOUSING U27517
137	RTA58-U27585	锁板	LOCKING PLATE FOR U27523, U27528, U27529 & U27534
138	RTA58-U27586	锁板	LOCKING PLATE FOR SCREW U27578
139	RTA58-U27703	阀体	VALVE BODY FOR RELIEF VALVE
140	RTA58-U27721	示功阀	INDICATOR VALVE
141	RTA58-U34004	锁闭圆盘	LOCKING DISC FOR NUT
142	RTA58-U34012	锁板	LOCKING PLATE FOR FLANGE U34010
143	RTA58-U34013	锁板	LOCKING PLATE FOR LOCKING DISC U34003
144	RTA58-U34014	O型圈	O-RING FOR U34005 & U34006
145	RTA58-U34015	O型圈	O-RING FOR RUNNING PIPE U34230
146	RTA58-U34016	圆橡胶环	ROUND RUBBER RING FOR PISTON SKIRT
147	RTA58-U34017	橡胶圈	ROUND RUBBER RING BETWEEN PISTON UPPER PART AND 1
148	RTA58-U34100	活塞头	PISTON HEAD, COMPLETE (U34101-U34108)
149	RTA58-U34101	活塞头	PISTON HEAD
150	RTA58-U34107	弹性螺栓	ELASTIC STUD ON PISTON
151	RTA58-U34121	活塞裙	PISTON SKIRT, COMPLETE
152	RTA58-U34123	橡胶圈	RUBBER RING FOR PISTON SKIRT
153	RTA58-U34231	螺母	NUT FOR U34005 AND U34006
154	RTA58-U34401	活塞环	PISTON RING
155	RTA58-U34402S	活塞环	PISTON RING
156	RTA58-U36204	GUIDE RING ON GLAND BOX	GUIDE RING ON GLAND BOX
157	RTA58-U36205	JOINT RING IN 3-PARTS ON GLAND BOX ,COMP	JOINT RING IN 3-PARTS ON GLAND BOX ,COMPLETE

158	RTA58-U36206	SCRAPER RING IN 3-PARTS ON GLAND BOX	SCRAPER RING IN 3-PARTS ON GLAND BOX COMPLETE
159	RTA58-U36207	CLAMP ON GLAND BOX	CLAMP ON GLAND BOX
160	RTA58-U36214	锁板	LOCKING PLATE FOR FIXING SCREW AT THE
161	RTA58-U43141	控制阀	CONTROL VALVE FOR STARTING CONTROL VALVE,COMPLETE
162	RTA58-U46113	二位三通阀	3/2 WAY VALVE
163	RTA58-U55260	PLUNGER WITH BUSH AND SPRING CARRIER, COMPLETE, FOR FUEL INJECTION PUMP	PLUNGER WITH BUSH AND SPRING CARRIER,COMPLETE, FOR FUEL INJECTION PUMP
164	RTA58-U55475	排气阀驱动泵导承	ROLLER GUIDE,COMPLETE
165	RTA58-U55503	排气阀驱动泵活塞	PISTON FOR ACTUATOR PUMP
166	RTA58-U55555	旋转制动销	ROTATIONAL SAFETY STUD
167	RTA58-U55564	排气阀驱动泵压缩弹簧	COMPRESSION SPRING FOR ROLLER GUIDE
168	RTA58-U55801	溢流阀	SPILL VALVE WITH SEAT, COMPLETE, FOR FUEL INJECTION PUMP
169	RTA58-U55805	输油阀	SUCTION OR DELIVERY VALVE WITH SEAT,COMPLETE, FOR FUEL INJECTION PUMP
170	RTA58-U55833	推杆	PUSH ROD WITH GUIDE BUSH AND SPRING,COMPLETE, FOR SUCTION AND SPILL VALVE
171	RTA58-U64672	CENTRE PIECE FOR SCAVENGE VALVE	CENTRE PIECE FOR SCAVENGE VALVE
172	RTA58-U64674	VALVE PLATE FOR SCAVENGE VALVE	VALVE PLATE FOR SCAVENGE VALVE
173	RTA58-U84454	O型圈	O-RING (FOR HOUSING U84437)
174	RTA58-U92062	ARRANGEMENT OF REMOTE THERMOMETER FOR EXHAUST GAS TEMPERATUR,COMPLETE	ARRANGEMENT OF REMOTE THERMOMETER FOR EXHAUST GAS TEMPERATUR,COMPLETE
175	U23101	刮油环总成	SCRAPER RING,COMPLETE
176	U23119	刮油环	OIL SCRAPER RING,COMPLETE
177	U23120	刮油环	OIL SCRAPER RING,COMPLETE
178	U23127	弹簧	EXT.SPRING FOR OIL SCRAPER
179	U23128	O 型圈	O-RING FOR UPPER HOUSING
180	U23130	O 型圈	O-RING FOR LOWER HOUSING
181	U27224	O 型圈	O-RING FOR HOUSING FOR FUEL INJECTION VALVE

182	U27240	油嘴	NOZZLE FOR FUEL INJECTION VALVE W/SHRUNK COMPL
183	U27414	启动阀座	VALVE SEAT
184	U27429	O 型圈	O-RING
185	U27430	O 型圈	O-RING
186	U27431	连接环	JOINT RING
187	U27510	O 型圈	O-RING
188	U27535	LOCKING TWO PARTS	LOCKING TWO PARTS
189	U27539	JOINT RING FOR SEALING AIR THROTTLE U27538	JOINT RING FOR SEALING AIR THROTTLE U27538
190	U-27543	JOINT RING SIGHT GLASS	JOINT RING SIGHT GLASS
191	U27549	O 型圈	O-RING
192	U27550	O 型圈	O-RING
193	U27555	连接环	JOINT RING
194	U27564	弹簧	TENSION SPRING
195	U27702	阀座	VALVE SEAT FOR RELIEF VALVE
196	U27703	阀体	VALVE BODY FOR RELIEF VALVE
197	U27722	适配器	ADAPTOR
198	U27723	法兰	FLANGE FOR INDICATOR VALVE
199	U36111	O 型圈	O-RING FOR CHEST H36120
200	U36203	SCRAPER RING ON GLAND BOX	SCRAPER RING ON GLAND BOX
201	U36210	拉伸弹簧	TENSION SPRING FOR SCRAPER RING
202	U36211	拉伸弹簧	TENSION SPRING FOR GUIDE
203	U55426	推力垫圈	THRUST WASHER
204	U55808	安全阀	RELIEF VALVE CPL 1150 BAR
205	U64674	阀盘	VALVE PLATE

CATALOGUE